

119-0219 T300, 119-0221 T550

NTP Network Time Server

Hardware Installation Guide

Models Covered: T300, T550

Document Number: T1201-01
27 January 2017

The latest version of this user guide can be obtained from www.TimeTools.co.uk.

DIREKTRONIK

 TimeTools

Important Safety Information:

Important Safety Information - Read the safety instructions before using this product.

1. Please read the manuals and retain for future reference. Please follow all instructions and heed all warnings.
2. Do not use this apparatus near water.
3. Clean only with dry cloth.
4. Install in accordance with the manufacturer's instructions.
5. Do not install near any heat sources such as radiators, heat registers, or other apparatus (including amplifiers) that produce heat.
6. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
7. Only use attachments as specified by the manufacturer.
8. The unit has no user serviceable parts inside. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
9. Use the mains plug to disconnect the apparatus from the AC mains. The mains plug shall remain easily accessible.
10. To completely disconnect unit power from the AC mains, disconnect the unit's power cord from the mains socket. To reconnect power, plug the unit's power cord into the mains socket following all safety instructions and guidelines.
11. Never push objects of any kind into this product through cabinet apertures as they may touch dangerous voltage points or short out parts that could result in fire or electric shock.

For PERMANENTLY CONNECTED EQUIPMENT, a readily accessible disconnect device shall be incorporated external to the equipment.

For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible.



CAUTION:

Before installing and configuring any T-Series NTP server appliance, please read the manuals and retain for future reference. Please follow all instructions and heed all warnings.

Full product documentation can be found on the supplied CD or at www.timetools.co.uk.

While reasonable efforts have been taken in the preparation of this document to ensure its accuracy, TimeTools Limited assumes no liability resulting from any errors or omissions in this manual, or from the use of the information contained herein.

All claims based on information publicly available at time of printing.

All product or service names mentioned in this document are trademarks of the companies with which they are associated.

Table of Contents

- 1. Introduction..... 5**
- 2. Key Features..... 5**
- 3. Scope of Supply..... 6**
 - 3.1. Optional Extras..... 6
- 4. Front Panel 7**
 - 4.1. LCD Display..... 7
 - 4.2. Alarm Indicator..... 7
 - 4.3. USB Port..... 7
- 5. Rear Panel..... 8**
 - 5.1. Power Inlet..... 8
 - 5.2. Ethernet Ports..... 8
 - 5.3. Console..... 8
 - 5.4. GPS/GNSS Antenna Connection..... 8
- 6. Installation..... 10**
 - 6.1. Locating the T300 T550..... 10
 - 6.2. Antenna Connection..... 10
 - 6.3. Connecting Ethernet..... 10
 - 6.4. Connecting RS232 Serial Console Cable..... 11
 - 6.5. Applying Power..... 11
- 7. Configuration..... 12**
- 8. Certification and Compliance..... 13**
 - 8.1. RoHS Compliance Statement..... 13
 - 8.2. REACH Regulation (EC) No 1907/2006..... 13
 - 8.3. Environmental Policy..... 13
 - 8.4. EC Declaration Of Conformity..... 13
- 9. Warranty..... 15**



1. Introduction

Network Time Protocol (NTP) can be used to synchronize the time on network clients, across an IP network, to the correct time of an NTP time server. TimeTools NTP Servers provide a stratum 1 NTP Time Server for ensuring the time is correct across an entire network.

The Network Time Server acquires time from the satellite constellation and distributes time across a network using the TCP/IP Network Time Protocol (NTP).



2. Key Features

Model T300: 16-channel, high sensitivity GPS timing receiver.

Model T550: 32-channel, multi-constellation timing receiver providing reception of GPS, GLONASS, BeiDou and is Galileo ready^{*1}.

Timing receiver synchronises to less than 15 nanoseconds (GPS Locked).

Can operate with outdoor, indoor or window located antenna, saving on cabling costs.

T550: Integrated high-stability TCXO oscillator provides holdover during loss of signal lock.

NTP accurate to less than 3 microsecond (3x10⁻⁶ seconds) UTC (GPS Locked).

Synchronize in excess of 100,000 clients.

Model T300: Single 10/100 Mbit auto-sensing, auto-MDIX Ethernet ports.

Model T550: Dual 10/100 Mbit auto-sensing, auto-MDIX Ethernet ports.

IPv4 and IPv6 Internet Protocol.

Integrated universal AC mains input PSU for world-wide operation.

Made in UK, with 6-year warranty and free lifetime support.

^{*1} Hardware ready: a firmware update is required to enable the Galileo constellation.

3. Scope of Supply

TimeTools T300 T550 shipment typically includes the following components:

T300 Models:

T300	NTP Time Server Appliance.
T-3040	GPS Antenna.

T550 Models:

T550	NTP Time Server Appliance.
T-3740	GNSS Antenna.

T300 and T550 Models:

MT4-GPS	Antenna Mount.
TCX-030	30m (100 ft) RG58 Cable.

IEC Power Lead.
RS232 Serial Console Lead.
Quick Start Guide.
CD containing user-guide, installation guide and white-papers.

3.1. Optional Extras

TCX-010	10m RG58 Cable.
TCX-030	30m RG58 Cable.
TCX-050	50m LMR195 Equivalent Cable.
TCX-100	100m LMR400 Equivalent Cable.

Custom cable lengths available on request.

SPP-GPS	Multi-strike maintenance-free surge suppressor
T-AD200-8	GPS Amplifier – 20db

GPS over optical fibre systems.
GPS Splitters – 2 to 32 way, compact or rack-mount.
Digital NTP Wall clocks.
Analog NTP Wall clocks.



4. Front Panel

The T300 T550 models have the following front panel indicators/connectors: LCD Display, Alarm, USB.



4.1. LCD Display

The T300 T550 are fitted with two line by 40 character ultra-bright backlit LCD displays for providing status and configuration information to the user. The display typically shows current time, system time offset compared to reference clock, NTP status, GPS status and number of satellites currently in use.

4.2. Alarm Indicator

A red / green bi-colour LED on the T300 T550 front panel indicates status and fault conditions.

4.3. USB Port

A USB port is provided for convenient and easy installation of firmware updates. Standard USB flash memory devices can be used for firmware updates.

5. Rear Panel

The rear panel of the T300 T550 models have the following connectors: Power, Eth0, Eth1 (T550 only) , Antenna, Console.



5.1. Power Inlet

Power to the appliance is applied via the double-fused IEC power entry inlet. The appliance accepts 100-240 VAC, 50-60Hz 0.1A. Fuse specification is two T 0.315A LBC 250V fuses.


5.2. Ethernet Ports

The T300 models have a single RJ45 10/100 Mbit auto-sensing, auto-MDIX Ethernet port labelled Eth0. The T550 models have dual RJ45 10/100 Mbit auto-sensing, auto-MDIX Ethernet ports labelled Eth0 and Eth1.

Link: 10/100 Mbit, auto-sensing, auto-MDIX
 Connector: RJ45
 Cable Type: CAT 5.0
 Modes: Half/Full Auto-negotiation.

5.3. Console

The Console port is a 9-way D-type female RS232 serial connection for device configuration using dumb terminal emulator. Null modem cable supplied for connection to standard 9-way PC serial interface.



RS232 Console port pin-outs:

Pin 2: RX
 Pin 3: TX
 Pin 5: GND

The appliance has a secondary serial port for optional serial time code output. It is combined into the same 9-way D-type connector as the console port. A custom serial cable is required to utilise the secondary serial port.

Secondary RS232 Serial Port pin-outs:

Pin 7: TXB
 Pin 8 : RXB

5.4. GPS/GNSS Antenna Connection

The GPS/GNSS antenna connector is a 50 ohm TNC female connector. It accepts a coax cable to a 5V GPS/GNSS antenna. Use only the antenna and cable supplied by TimeTools with the T300 T550.

Connector: TNC female, 50 ohm
Cable: Coax, 50 ohm
Antenna Output Voltage: 5VDC



6. Installation

6.1. Locating the T300 T550

Locate the appliance safely in a rack, on a shelf, or in a cupboard. The device should not be supported by the attached cables.

The appliance can be mounted into a 19" rack cabinet using standard rack-mounting hardware.



CAUTION:

Do not install the T300 T550 appliance where the operating ambient temperature may drop below 0°C (32°F) or exceed 50°C (122°F).

6.2. Antenna Connection

The T300 T550 antenna connection is a TNC female RF connector. It is provided for connection of an active 5 volt GPS antenna via a coax cable.



WARNING:

Any local installation regulations for outdoor or rooftop mounted antennas in the country where the antenna is installed must be observed.

Please refer to the GPS/GNSS Antenna Installation Guide (Document Number: T1202-01) for further information on antenna installation.

6.3. Connecting Ethernet

The T300 has a single 10/100 Mbit BaseT RJ45 auto-sensing, auto-MDIX Ethernet port.

The T550 has dual 10/100 Mbit BaseT RJ45 auto-sensing, auto-MDIX Ethernet port.

The auto MDI-X feature, automatically detects the required cable connection type and configures the connection appropriately, removing the need for crossover cables for peer to peer connection.

Connect one end of a CAT-5 patch cable to the RJ-45 network interface on the rear of the T300 T550. Connect the other end to a port on your network switch.

Alternatively, the T300 T550 can be connected directly to a host PC Ethernet network port using a CAT-5 patch cable for configuration purposes.



IMPORTANT:

When first installing the T300 T550 on your network, ensure that no other device on your network conflicts with the default IP address of the appliance.

Default IP Address (Eth0): 192.168.3.222

Default IP Address (Eth1): DHCP Client

6.4. Connecting RS232 Serial Console Cable

The T300 T550 Console port is a RS232 serial port on a standard 9-way D-type connector. The console serial port can be used to configure the device from a host PC.

Using the supplied null modem cable, connect the T300 T550 console port to the RS232 serial port on a PC.

A terminal emulation program, such as Hyper-Terminal or Putty, can then be used to configure the device.

Terminal settings:

Connect Using:	Direct to COMx	(where x is the serial port number)
Bits per second:	115200	
Data bits:	8	
Parity:	None	
Stop bits:	1	
Flow control:	None	
Terminal Emulation:	VT100 / ANSI	

Please refer to the T-Series User Guide (Document Number T1300-01) for configuration information.

6.5. Applying Power

Apply power by inserting the supplied mains cable into the IEC inlet at the rear of the NTP server and into an appropriate AC power source.



CAUTION:

For PERMANENTLY CONNECTED EQUIPMENT, a readily accessible disconnect device shall be incorporated external to the equipment.

For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible.

7. Configuration

Before configuring the NTP server, you will need to acquire the following basic configuration information:

IP address,
Network mask,
Default Gateway,
Domain name servers

or confirm availability of a network DHCP server for dynamic networking configuration.

The T300 T550 can be configured in any one of three ways:

- Over a network using a web browser on a PC connected to the same network segment.
- Using a web browser on a PC using a peer-to-peer (direct cable) network connection.
- Using a dumb terminal emulator on a PC using a RS232 serial connection.

Please refer to the T-Series User Guide (Document Number T1300-01) for configuration information.

8. Certification and Compliance

8.1. RoHS Compliance Statement

This document certifies that the products manufactured by TimeTools do not contain the substances listed in the table below in the concentrations exceeding the Maximum Concentration Value (MCV).

Substance Maximum Concentration Value

Lead 0.1% by weight (1000 ppm)
 Mercury 0.1% by weight (1000 ppm)
 Cadmium 0.01% by weight (100 ppm)
 Hexavalent Chromium 0.1% by weight (1000 ppm)
 Polybrominated Biphenyls (PBB) 0.1% by weight (1000 ppm)
 Polybrominated Diphenyl Ethers (PBDE) 0.1% by weight (1000 ppm)

Products containing the substances listed in the table above, in concentrations below the MCV, are understood to be in compliance with Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronics equipment (RoHS Directives). The stated components are deemed as compliant as accord to definitions given in the directives (refer to directives). This document also certifies that the materials declaration as provided by TimeTools is accurate to the best of our knowledge.

8.2. REACH Regulation (EC) No 1907/2006

TimeTools hereby certifies that to the best of its knowledge, and based on our suppliers' information, parts and products produced by TimeTools do not contain any of the substances referenced in the current list of Substances of High Concern (SVHCs are defined in Article 57 of Regulation (EC) No 1907/2006.) in concentrations greater than 0.1% weight by weight.

8.3. Environmental Policy

TimeTools is committed to minimising the risk of any environmental damage or pollution caused by the company . We ensure compliance with EU Directive 2002/96/EC Waste Electrical and Electronic Equipment, more commonly known as the "WEEE directive".

The WEEE Directive aims to:

Reduce waste associated with electrical and electronic equipment.

Improve the environmental performance of companies involved in the life cycle of electrical and electronic equipment.

For further information on the WEEE Directive or if you would like to arrange the collection and disposal of an old, unserviceable or redundant piece of equipment that was originally supplied by TimeTools, please contact TimeTools via email at info@timetools.co.uk

8.4. EC Declaration Of Conformity

Please see the EC Declaration Of Conformity for TimeTools T300 and T550 models below.



EC Declaration Of Conformity

We: *TimeTools Limited*

Of: *Unit 34 Wombourne Enterprise Park, Bridgnorth Road, Wombourne, South Staffordshire. WV5 0AL. UK.*

Declare that: TimeTools T300, T550 NTP Servers

In accordance with the following directives:

1999/5/EC	R&TTE Directive.
2011/65/EU	Restriction of the use of certain hazardous substances.
93/68/EEC	CE marking and its amendments.

has been designed and manufactured to the following standards:

Safety:	EN 60950-1: 2006+A2: 2013	Information Technology Equipment Part 1: General Requirements.
EMC:	ETSI EN 301 489-1: V1.9.2 (2011-09)	EMC standard for radio equipment and services.
	ETSI EN 301 489-3: V1.6.1 (2013-08)	Specific conditions for Broadband Data Transmission System.
	ETSI EN 300 440-2 V1.4.1 (2010-08)	Radio Spectrum Efficiency
	EN 61000-3-2: 2014	Mains Harmonics
	EN 61000-3-3: 2013	Voltage fluctuations and Flicker
RoHS:	EN 50581:2012	Restriction of hazardous substances.

I hereby declare that the equipment named above has been tested and found to comply with the relevant sections of the above referenced specifications. The unit complies with all essential requirements of the directive.

Signed by:



Name: Andrew Shinton
Position: Managing Director
Place and Date: TimeTools Limited, 12 April 2017



9. Warranty

TimeTools Limited warrants the T300 and T550 appliances to be free from defects in material and workmanship during a six-year period.

TimeTools Limited warrants GPS/GNSS antennas , GPS amplifiers, antenna cables and any integral batteries to be free from defects in material and workmanship during a 12-month period.

The Warranty begins on the date the unit is shipped from TimeTools.

TimeTools' liability under this Warranty is limited to repairing or replacing, at TimeTools' option, the defective equipment and providing upgrade version changes for firmware. In case of repair, the product must be returned to an authorized TimeTools Solutions Service Centre.

This Warranty does not apply if repairs are required due to acts of nature beyond TimeTools' control such as, but not limited to, lightning strikes, power surges, misuse, damage, neglect, or if repairs/modifications have been made or attempted by anyone other than personnel authorized by TimeTools.

Disclaimer

IN NO EVENT WILL TIMETOOLS LIMITED BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FROM THE SALE OR USE OF THIS PRODUCT.

THIS DISCLAIMER APPLIES BOTH DURING AND AFTER THE TERM OF THE WARRANTY. TIMETOOLS LIMITED DISCLAIMS LIABILITY FOR ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A SPECIFIC PURPOSE.

Repair and Returns

To obtain service under this Warranty, contact TimeTools at the address below during the Warranty period to receive a Return Material Authorization (RMA) number and shipping instructions. Then ship the product, transportation prepaid, for inspection.

Ship to:

TimeTools Limited
Attn: RMA XXXXXXXX
Unit 34, Wombourne Enterprise Park,
Bridgnorth Road, Wombourne,
South Staffordshire.
WV5 0AL.
UK

One-way shipping is the Customer's responsibility. TimeTools will pay the charges to return ship the equipment. However, if the returned product is not found to be defective, then the buyer will be liable for all shipping charges. If the buyer is located outside of the UK, then they will be liable for any duties and taxes payable, if applicable.

TimeTools will not be responsible for dismounting and remounting of the NTP server, for unauthorized returns or for returns that do not list the RMA number and quantity returned on a packing list attached in plain view on the outside of the shipping container.

TimeTools Limited.
Unit 34, Wombourne Enterprise Park,
Bridgnorth Road, Wombourne,
South Staffordshire.
WV5 0AL. UK

Tel: +44 (0) 1902 897400
Fax: +44 (0) 870 123 1844
Email: info@TimeTools.co.uk
Web: www.TimeTools.co.uk